



TECHNICAL DATA SHEET

SUPER EDGE CERAMIC CUP WHEEL 200#

PRODUCT DESCRIPTION

The Concrete Protector's Super Edge Ceramic Cup Wheel 200# is used for medium aggregate exposure. Specially designed for edgework.

STANDARD COLORS: Brownish- Tan
OTHER COLORS AVAILABLE: N/A
REVISION DATE: January 26, 2026

CURE SCHEDULE (75°)

POT LIFE (1.5 GAL VOLUME): N/A

TACK FREE (DRY TO TOUCH): N/A

RECOAT OR TOPCOAT: N/A

LIGHT FOOT TRAFFIC: N/A

FULL CURE: N/A

COVERAGE

Recommended for use on concrete in which the Scientific Concrete Polishing System is being installed.

COVERAGE: 2,000-5,000 sq. ft.

MIX RATIO: N/A

RECOMMENDED FILM THICKNESS: N/A

PACKAGING INFORMATION: 1 piece

PHYSICAL PROPERTIES

FLEXURAL STRENGTH: N/A

DIAMETER: 5"

TENSILE STRENGTH: N/A

ADHESION: N/A

VISCOSITY: N/A

ABRASION RESISTANCE: N/A

ULTIMATE ELONGATION: N/A

HARDNESS: N/A

VOLATILE ORGANIC CONTENT: N/A

SHELF LIFE: N/A

CHEMICAL RESISTANCE

N/A

LIMITATIONS

- Do not exceed maximum operating speed indicated on wheel
- Use with hand grinders or walk behind edge machines

BENEFITS

- Reduce steps and labor costs on edge
- Medium grind and smooth scratch pattern
- Can be used wet or dry
- Easy to transfer polishing steps



TECHNICAL DATA SHEET

SUPER EDGE CERAMIC CUP WHEEL 200#

INSTRUCTIONS

- 1) Position the Flanges- Inner flange (larger, flat side) goes against the grinder's shoulder. Outer flange (with raised hub) helps secure the wheel.
- 2) Place the Super Edge Ceramic Cup Wheel 200# onto the spindle: The arrow on the wheel should match the grinder's rotation direction. The wheel should sit flat against the inner flange.
- 3) Thread the arbor nut back onto the spindle by hand to prevent cross-threading. Use the grinder wrench to snug the nut — don't overtighten (snug is enough).
- 4) Apply light, even pressure — don't force the wheel into the surface. nKeep the wheel cool by not dwelling too long in one spot

NOTICE TO BUYER: DISCLAIMER OF WARRANTIES AND LIMITATIONS ON OUR LIABILITY:

The Concrete Protector (Division of Incredible Products, LLC), guarantees that all products are assembled under rigorous quality assurance specifications and that all information supplied is exact. All information supplied is not to be taken as a warranty, but for you to conduct your own test to determine if the given product is suitable for your distinct purpose. The following list of properties should not be interpreted as specifications. CONVEYED OR SUGGESTED, NO WARRANTY IS BUILT UPON ANY DISCOVERED RESULTS OR INFORMATION YOU WILL OBTAIN DURING USE. CONVEYED OR SUGGESTED NO WARRANTY IS BUILT THAT THE GIVEN PRODUCT SHALL BE MARKETABLE OR THAT THE GIVEN PRODUCT WILL BE FIT FOR ANY DISTINCT PURPOSE. NO WARRANT IS BUILT UPON SAID INFORMATION OR THAT THE GIVEN PRODUCT WILL NOT INFRINGE UPON ANY PATENT. The Concrete Protector is NOT liable for, direct or indirect, inadvertent or consequential damages. The Concrete Protector's liability is and will only be limited to the net selling price of our products or, at our discretion, the replacement of our products. Upon delivery of our products, your acceptance means that you accept all terms of this warranty even if other documents and or purchase orders astray from the terms of this warranty. No representative, on our behalf, is permitted to make any representation, warranty, or assume liability with any sale of our products. OUR PRODUCTS CONTAIN CHEMICALS THAT CAN CAUSE SERIOUS PHYSICAL INJURY. BEFORE THE USE OF OUR PRODUCTS, READ ALL MATERIAL AND FOLLOW ALL LISTED PRECAUTIONS TO AVOID ANY BODILY HARM.

SUPER EDGE CERAMIC CUP WHEEL 200#